

2018

A7 | S7 | RS 7

Quick Questions & Answers



Introduction to your A7

Navigation

Start/Stop System

Climate Control

Cruise Control

Audi smartphone interface

Bluetooth® & Voice Recognition



- 1. Start Engine Stop Button**
With key fob in vehicle, pressing this button starts the engine and shuts the engine off when vehicle is in park.
- 2. MMI® Controls**
MMI controls consist of a control knob, control buttons and function buttons. Turn the control knob to the left or right and press it to make a selection in the MMI.
- 3. MMI® Touchpad**
The MMI touchpad can be used to write letters and numbers or access preset radio stations. The touchpad control also allows you to navigate apps within the optional Audi smartphone interface.
- 4. Navigation**
Get started with setting destinations and discover more as you become familiar with the interface.
- 5. Electromechanical Parking Brake**
Pull the switch up to engage the parking brake. To release, depress the brake pedal and push the switch down.
- 6. Climate Control**
When AUTO is selected, the system maintains your temperature selection by regulating air temperature, fan speed and airflow.
- 7. Start/Stop System**
This advanced Audi technology is designed to help save fuel and reduce CO₂ emissions at the same time.
- 8. Media**
Press the MEDIA button to access available media from connected sources (e.g., Bluetooth audio, optional USB and more).
- 9. MMI® Display**
The MMI screen displays menus and multi-media information, including Voice Recognition commands, media selections and radio information.
- 10. Voice Recognition**
Press the TALK button on the steering wheel to activate Voice Recognition in the MMI. A longer press will activate Siri® Voice Control or Talk to Google when Audi smartphone interface is active or a Bluetooth connection* is established.
- 11. Driver Information System (DIS)**
The DIS provides important driver information, navigation, including trip computer data, outside temperature and vehicle alerts.
- 12. DIS Controls**
The Driver Information System is controlled with the multifunction steering wheel controls. To select a menu item, turn and press the thumbwheel.
- 13. Cruise Control**
To activate, pull the stalk toward you. Braking or pushing the stalk away slightly will cancel Cruise Control.

**iPhone® users ensure Siri is enabled.*

Introduction to your A7

Navigation

Start/Stop System

Climate Control

Cruise Control

Audi smartphone interface

Bluetooth® & Voice Recognition

Audi Navigation

Setting a Destination

Your MMI Navigation system has extraordinary capabilities to enhance your drive with user-definable views, routing selections and more. Get started with setting destinations and discover more as you become familiar with the interface.

1. Press the NAV function button.
2. Select the Destination control button.
3. Many methods of entering information for Navigation can be selected from this menu. One method is to select Free search from the Navigation menu.
4. Using the MMI touchpad, enter the address information, starting with street number and address. Address information will populate as you enter the address. When the address is displayed, use the control knob to select.
5. When completed, select Start route guidance.



Alternative Routes

- ▶ After entering an address and before starting route guidance, select Display alternative routes.
- ▶ Or while there is an active route, press the Route button and select Display alternative routes.
- ▶ If available, up to three route suggestions will be displayed and can be selected using the control knob. (Route type: 1 fast, 2 fast alternative, 3 economic route.)



Note:
Always pay careful attention to the road and do not drive while distracted. Enter destinations while vehicle is stationary away from traffic. When pressing the iNav button, the last navigation announcement will be repeated.

- ⚠ **Warnings: Navigation**
 - ▶ The demands of traffic require your full attention.
 - ▶ Obey all traffic laws when driving.
 - ▶ The route calculated by your navigation system is recommended for reaching your destination. Obey traffic lights, stopping restrictions, one-way streets, lane change restrictions, etc.

Navigation

Start/Stop System

Climate Control

Cruise Control


Audi smartphone interface

Bluetooth® & Voice Recognition

Start/Stop System

Operation

The Start/Stop System shuts off the engine when you stop at traffic signals or during certain stop-and-go driving conditions to save fuel. When conditions are met and the engine shuts off, the Start/Stop System light appears in the Driver Information System in the instrument cluster. Releasing the brake pedal instantly restarts the engine and makes power available before your foot even reaches the accelerator.



For the A7 3.0L TFSI models, the Start/Stop function engages to turn off the engine at speeds below approximately 2 mph in situations where the vehicle senses you are coming to a complete stop. This helps achieve improved fuel economy, while making the stop engagement of the engine more seamless. For the S7 4.0L TFSI, the engine stop function is not engaged until a full stop has been achieved.

Start/Stop ON or OFF?

If you wish to turn off the Start/Stop System, simply press the **(A) OFF** button located below the MMI display. The button will illuminate to tell you the Start/Stop System is deactivated. When the system is deactivated, the engine will continue to run when the vehicle is stopped at traffic signals or during stop-and-go driving; therefore you will not receive the potential fuel savings or CO₂ reduction benefit.



Vehicle Engine Type	Auto Start/Stop Mode
Audi A7 3.0L TFSI	Default ON
Audi S7 4.0L TFSI	Last Mode
Audi RS 7 4.0L TFSI	n/a

- ▶ **Default ON**
If you turn off Auto Start/Stop, it will default back to ON the next time the vehicle is started.
- ▶ **Last Mode**
Auto Start/Stop continues in the last selected mode when the vehicle is restarted.

⚠ Warnings: Start/Stop System

- ▶ Always switch the Start/Stop system off when driving through water.
- ▶ Never allow the engine to run in a confined space, because this increases the risk of asphyxiation.

Start/Stop System

Climate Control

Cruise Control

Audi smartphone interface

Bluetooth® & Voice Recognition

4-Zone Climate Control

1. AUTO Setting

The AUTO setting of your Climate Control system will help the cabin maintain your selected temperature by regulating the temperature, fan speed and airflow. Once activated, there is no need to alter the settings. When AUTO is selected, A/C will come on automatically to condition and dehumidify the air.



Dual Temperature Settings

Temperature and airflow can be operated independently for each side of the cabin using the control knobs. AUTO will maintain separate temperatures for the driver and front passenger.

2. Synchronize Zones

Pressing the SYNC button will synchronize the driver and passenger side controls along with the rear settings to the same temperature, fan speed and airflow. The synchronization disengages once a passenger adjusts their temperature setting.

3. Seat Heating/Seat Ventilation

Press the  or the  button to turn the heat seating or ventilation on at the highest level. To reduce the temperature of the seat heating or slow seat ventilation, press the seat heating or seat ventilation button again. To turn the seat heating or seat ventilation off, press the appropriate button repeatedly until the LED turns off.

4. Fan Speed

Fan speed can be operated independently. To change the speed, press the  button followed by turning either the driver or passenger control knob.

Residual Heat

Use the fan button to turn the residual heat function of the Deluxe Climate Control on or off. Residual Heat uses the heat from the engine coolant to maintain a comfortable cabin temperature when the engine is off.

- ▶ If the ignition is switched off and the engine is warm, the residual heat from the engine is used to continue to heat the passenger compartment.
- ▶ The function switches off after 30 minutes or if the battery charge is low.



5. Recirculation

The recirculation function helps prevent outside air and odors from entering the cabin. It may also be used in conjunction with A/C to cool the cabin more quickly.

6. Air Distribution

The airflow button directs air to the floor, panel or defrost vents, or a combination. Pressing the button multiple times will toggle between different airflow settings.

⚠ Warnings: Climate Control

- ▶ Poor visibility can lead to accidents.
- ▶ For safer driving, keep all windows free of ice, snow and fog.
- ▶ Become familiar as quickly as possible with the correct use and function of the climate control system, especially with the defrosting and defogging function.
- ▶ When the temperature is below freezing, only use the windshield washer system after the windshield has been warmed by the climate control system. The washer fluid could freeze on the windshield and impair visibility.
- ▶ You should not use the recirculation mode for an extended period of time since no fresh air is drawn in. With the air-conditioning switched off, the windows can fog up, which increases the risk of an accident.
- ▶ Individuals with reduced sensitivity to pain or temperature could develop burns when using the seat heating function. To reduce the risk of injury, these individuals should not use seat heating.

Climate Control

Cruise Control

Audi smartphone interface

Bluetooth® & Voice Recognition

Cruise Control

Activate

To activate, pull the control stalk toward you to put it in the ON position.

Set Cruising Speed

At your desired speed, press the SET button at the end of the stalk. The set speed and the illuminated CRUISE icon are shown in the Driver Information Display.

Changing Speed

There are several ways to change your speed:

- ▶ Accelerate or decelerate, then press the SET button again.
- ▶ Push the stalk up or down one detent to increase/decrease speed in 1 mph increments.
- ▶ Push the stalk up or down to the second detent and release to increase/decrease speed in 5 mph increments.
- ▶ Hold the stalk up or down to increase/decrease speed; release when desired speed is reached.

Cancel/Resume

1. To cancel, press the brake pedal or push the stalk slightly away from you to the CANCEL position.
2. The CRUISE indicator light will go off.
3. To resume, pull the stalk toward you; you will return to your set speed.

Your most recently set speed appears as a small icon in the Driver Information Display. It remains in memory until you turn Cruise Control or your Audi off.

Adaptive Cruise Control*

Adaptive Cruise Control (ACC) helps you maintain a safe distance between you and vehicles in front of you, eliminating the need to reset your Cruise Control after braking. When you approach a slower-moving vehicle in front of you, ACC will automatically slow down to that vehicle's speed and maintain a safe distance. When the vehicle is no longer present, ACC will accelerate back to the stored speed.

There are four preset distance settings that can be adjusted using the distance switch on top of the stalk. The default is distance 3 and will reset to that each time you turn on the ignition.

Changing Speed with Adaptive Cruise Control Active

- ▶ Push the stalk up or down one detent to increase/decrease speed in 2.5 mph increments.

Note:

*Optional feature available on select trim lines.

⚠ Warnings: Adaptive Cruise Control

- ▶ Always pay attention to traffic when ACC is switched on and braking guard is active. As the driver, you are still responsible for starting and for maintaining speed and distance to other objects. Braking guard is used to assist you. The driver must always take action to avoid a collision. The driver is always responsible for braking at the correct time.
- ▶ For safety reasons, do not use ACC when driving on roads with many curves, when the road surface is in poor condition and/or in bad weather (such as ice, fog, gravel, heavy rain and hydroplaning). Using the system under these conditions increases the risk of an accident.
- ▶ Switch ACC off temporarily when driving in turning lanes, on expressway exits or in construction zones. This prevents the vehicle from accelerating to the stored speed when in these situations.
- ▶ The ACC system will not brake by itself if you put your foot on the accelerator pedal. Doing so can override the speed and distance regulation.
- ▶ When approaching stationary objects such as stopped traffic, ACC will not respond and braking guard will have limited function.
- ▶ The ACC system and braking guard do not react to people, animals, objects crossing the road or oncoming objects.
- ▶ The function of the radar sensors can be affected by reflective objects such as guard rails, the entrance to a tunnel, heavy rain or ice.
- ▶ Improper use of ACC can cause collisions, other accidents and serious personal injury.
- ▶ Never let the comfort and convenience that ACC and braking guard offer distract you from the need to be alert to traffic conditions and the need to remain in full control of your vehicle at all times.
- ▶ Always remember that the ACC and braking guard have limits - they will not slow the vehicle down or maintain the set distance when you drive towards an obstacle or something on or near the road that is not moving, such as vehicles stopped in a traffic jam, a stalled or disabled vehicle. If registered by the radar sensors, vehicles or obstacles that are not moving can trigger a collision warning and if confirmed by the video camera, an acute collision warning.
- ▶ Never follow a vehicle so closely that you cannot stop your vehicle safely. The ACC cannot slow or brake the vehicle safely when you follow another vehicle too closely. Always remember that the automatic braking function cannot bring the vehicle to a sudden or emergency stop under these conditions.
- ▶ To prevent unintended operation, always switch ACC off when it is not being used.
- ▶ It is dangerous to ACC and resume the stored speed when the current road, traffic or weather conditions do not permit this. This increases the risk of an accident.
- ▶ Always obey applicable traffic laws, use good judgment, and select a safe following distance for the traffic, road and weather conditions.
- ▶ Lack of attention can cause collisions, other accidents and serious personal injuries. The braking guard is an assist system and cannot prevent a collision by itself. The driver must always intervene. The driver is always responsible for braking at the correct time.
- ▶ Always pay close attention to traffic, even when the braking guard is switched on. Be ready to intervene and be ready to take complete control whenever necessary. Always keep the safe and legal distance between your vehicle and vehicles up ahead.
- ▶ Braking guard works within limits and will not respond outside the system limits, for example when approaching a stopped vehicle or stationary obstacle (end of a traffic jam or vehicle that has broken down in traffic).
- ▶ Always remember that the radar sensor for the braking guard works only within defined detection and range limits that may prevent the proper detection of other vehicles.
- ▶ The radar sensor's function and range can be reduced by rain, snow and heavy spray. Moving vehicles up ahead may not be promptly detected or may not be detected at all.

⚠ Warnings: Cruise Control

- ▶ Always pay attention to the traffic around you when the Cruise Control system is in operation. You are always responsible for your speed and the distance between your vehicle and other vehicles.
- ▶ For safety reasons, Cruise Control should not be used in the city, in stop-and-go traffic, on winding roads and when road conditions are poor (such as ice, fog, gravel, heavy rain and hydroplaning), because this increases the risk of an accident.
- ▶ Switch the Cruise Control off temporarily when driving in turning lanes, highway exits or in construction zones.
- ▶ Please note that unconsciously "resting" your foot on the accelerator pedal prevents the Cruise Control from braking. This is because pressing the accelerator pedal overrides the Cruise Control system.
- ▶ If a brake system malfunction such as overheating occurs when the Cruise Control system is switched on, the braking function in the system may be switched off. The rest of the Cruise Control system functions remain active as long as the CRUISE indicator light is on.
- ▶ You should only resume the stored speed if it is not too high for existing traffic conditions. Otherwise you can increase the risk of an accident.



Cruise Control

Audi smartphone interface

Bluetooth® & Voice Recognition

Audi smartphone interface

Connecting

You can connect your Apple® iPhone or Android™ phone to the MMI. Certain content on your phone will be adapted to the Infotainment system display and can be operated through the MMI controls**. This gives you the benefit of the familiarity with your phone's system combined with the MMI display along with the ease of your phone's voice recognition system.

To connect:

1. Ensure your phone has the most current operating system.
2. The vehicle must be stationary with the ignition on.
3. Connect your smartphone with a manufacturer approved cable to either USB port*.
4. For Android Auto™, start the Android Auto app on your phone. You must have an active Google account and Internet connection**.
5. On initial connection, you will see a prompt in the MMI. Using the control knob, select to activate the device and agree to the data transfer.
6. Respond to prompts as necessary from both the MMI as well as the smartphone.

Once connected, you have access to the apps displayed on the screen.

Apple CarPlay™/Android Auto™ Operation

Both systems use similar controls to operate their respective functions. Common controls include the control knob to choose onscreen options, move through menus or select items. While Apple CarPlay is activated, all Bluetooth capability*** is disabled.

Using CarPlay®:

- ▶ Use the control knob to move and select app, press to open.
- ▶ You can also use the left/right, up/down arrows on the touchpad to move to a different screen/menu.
- ▶ Use the touchpad arrows to jump levels in a menu list.
- ▶ Press the BACK button to return to the menu of the active app.
- ▶ A long press of the TALK button activates Siri Voice Control.
- ▶ Enter navigation information using Siri Voice Control.




With Apple CarPlay™ and Android Auto™ you can:

- ▶ With a long press of the TALK button on the steering wheel use the digital assistant, "Siri" Voice Control™ or "Talk to Google".
- ▶ Make and receive calls.
- ▶ Send and receive text messages.
- ▶ Set reminders.
- ▶ Get turn-by-turn navigation.
- ▶ See recent places.
- ▶ Listen to music apps.


After the initial connection of a phone with CarPlay® or Android Auto, it will automatically activate CarPlay or Android Auto the next time it is connected, unless you have deactivated the function before disconnecting the cable.

Using Android Auto™:

- ▶ Use the down touchpad arrow to access the menu bar and select apps.
- ▶ Use the touchpad arrows or upper left/right control buttons to move to a different level/menu.
- ▶ Use your finger on the touchpad to move the view within a map.
- ▶ Where applicable, touch the down touchpad arrow to enter the spell mode.
- ▶ Use your finger on the touchpad to enter text or numerals instead of the speller.
- ▶ A long press of the TALK button or upper right control button activates Talk to Google.



Allows use of the touchpad to move within screens and menus.



Allows use of the touchpad to move within screens and menus. For Android devices, you can also use it to enter alphanumeric characters.

Deactivating and Reactivating Apple CarPlay™ or Android Auto™

While in CarPlay or Android Auto, you may access certain MMI functions such as Navigation and Radio by pressing the respective function button. CarPlay or Android Auto remains connected in the background. CarPlay and Android Auto can be deactivated, allowing you to simply charge your phone, prevent automatic connection or access full MMI functionality.

To Deactivate:

1. Select the Menu function » Setup » Deactivate CarPlay or Deactivate Android Auto.
2. Return to the main MENU or press any function button.

To Reactivate and Enable Automatic Reconnection, Follow These Steps:

1. From the MENU screen, select Audi smartphone.
2. If the screen shows no device connected, select Switch to device list.
3. Choose your device.
4. Select Activate CarPlay or Activate Android Auto.
5. Scroll to Audi smartphone interface and ensure there is a check in the box for your device.

*Non-certified cables may not support data transfer or maintain a reliable connection.

**For Android Auto, visit g.co/autocheck on your phone's browser to see if it's compatible. Not all apps work with the Audi smartphone interface, and some functions may be limited. Available functions depend on the operating system version and the capabilities of the app. CarPlay requires iPhone 5 or newer. Some MMI functions may not be available when Apple CarPlay or Android Auto is active. Refer to www.apple.com/ios/carplay/ or www.android.com/auto/ for additional information.

***Android Auto will maintain or establish a Bluetooth connection to the connected device.

Note:

Audi smartphone interface requires compatible device, operating system and mobile app. Standard text and data rates apply. See mobile app provider for terms and privacy. Apple CarPlay is a trademark of Apple Inc. Siri must be enabled on device to activate Siri features.

⚠ Warnings: Audi smartphone interface

- ▶ Only use the infotainment system when traffic conditions permit and always in a way that allows you to maintain complete control over your vehicle.
- ▶ Always make sure that you follow the instructions and heed the WARNINGS in this Manual. It is in your interest and in the interest of your passengers.
- ▶ Always keep the complete Owner's literature in your Audi when you lend or sell your vehicle so that this important information will always be available to the driver and passengers.
- ▶ Always keep the Owner's literature handy so that you can find it easily if you have questions. Driving requires your complete and undivided attention. As the driver, you have complete responsibility for safety in traffic. Never operate mobile devices while driving, because this increases the risk of an accident.

Audi smartphone interface


Bluetooth® & Voice Recognition

Bluetooth® Pairing

Pairing a Compatible Phone

Bluetooth pairing is a one-time procedure. Once paired via Bluetooth, your phone will automatically connect when you start your vehicle* and your phone's contacts automatically synchronize, allowing you to retrieve contacts and make and receive calls through the Infotainment system. For more information regarding phone compatibility visit audiusa.com/bluetooth.

1. Switch ignition to Accessories mode.
2. Enable the Bluetooth in your phone's Settings and set to pairing or search mode.
3. Select Audi MMI when it appears on the phone's screen.
4. Use the MMI control knob to select Yes.
5. Confirm that the six-digit PIN displayed matches the PIN displayed on your phone, and select Yes.
6. Select Pair on your phone to complete the pairing process.



Two active phones can be connected simultaneously to receive calls through the MMI, giving you primary and secondary devices. If the primary phone is in use, the secondary phone will only receive calls from the phone, not the MMI system.

To pair an additional phone, follow steps 1-6 above. Both contact lists/directories from each device will be loaded into the MMI.

Switch Roles:

1. Press the TEL function button and choose Switch roles.



**Some phones may require a response to automatically connect for future connections. Once paired, the Bluetooth symbol appears on the MMI screen along with network strength bars, and it will be displayed whenever a paired phone is connected to the Infotainment system.*



Note:

Bluetooth® Pairing

See your phone's Owner's Manual for specific Bluetooth activation instructions. Vehicle must be stationary with the parking brake engaged while performing this operation. Once paired, the Bluetooth symbol appears in the MMI screen along with network strength bars and it will be displayed whenever a paired phone is connected to the infotainment system.

⚠ Warnings: Bluetooth® Pairing

- ▶ Medical experts warn that cell phones can interfere with the function of pacemakers. Always maintain a minimum distance of 20 centimeters between the cell phone antenna and the pacemaker.
- ▶ Do not carry the cell phone in a pocket directly over the pacemaker when the phone is switched on.
- ▶ Switch the cell phone off immediately if you suspect it may be interfering with the pacemaker.
- ▶ Switch your cell phone off in areas where there is a risk of an explosion. These locations are not always clearly marked. This may include gas stations, fuel and chemical storage facilities or transport vehicles, or locations where fuel vapors (such as propane or gasoline vapor in vehicles or buildings), chemicals or large quantities of dust particles (such as flour, sawdust or metal) may be present in the air. This also applies to all other locations where you would normally turn your vehicle engine off.
- ▶ The demands of traffic require your full attention.
- ▶ Obey all applicable laws regarding use of telephones in vehicles.
- ▶ Switch off the telephone where use of cell phones is prohibited. Obey all applicable notices and regulations.

⚠ Warnings: Voice Recognition

- ▶ Direct your full attention to driving. As the driver, you have complete responsibility for safety in traffic. Only use the functions in such a way that you always maintain complete control over your vehicle in all traffic situations.
- ▶ Do not use the Voice Recognition system in emergencies because your voice may change in stressful situations. It may take longer to dial the number or the system may not be able to dial it at all. Dial the emergency number manually.

Bluetooth® Pairing

Pairing a Compatible Phone

Bluetooth pairing is a one-time procedure. Once paired via Bluetooth, your phone will automatically connect when you start your vehicle* and your phone's contacts automatically synchronize, allowing you to retrieve contacts and make and receive calls through the Infotainment system. For more information regarding phone compatibility visit audiusa.com/bluetooth.

1. Switch ignition to Accessories mode.
2. Enable the Bluetooth in your phone's Settings and set to pairing or search mode.
3. Select Audi MMI when it appears on the phone's screen.
4. Use the MMI control knob to select Yes.
5. Confirm that the six-digit PIN displayed matches the PIN displayed on your phone, and select Yes.
6. Select Pair on your phone to complete the pairing process.



Two active phones can be connected simultaneously to receive calls through the MMI, giving you primary and secondary devices. If the primary phone is in use, the secondary phone will only receive calls from the phone, not the MMI system.

To pair an additional phone, follow steps 1-6 above. Both contact lists/directories from each device will be loaded into the MMI.

Switch Roles:

1. Press the TEL function button and choose Switch roles.

**Some phones may require a response to automatically connect for future connections. Once paired, the Bluetooth symbol appears on the MMI screen along with network strength bars, and it will be displayed whenever a paired phone is connected to the Infotainment system.*



Read Messages

Your Audi vehicle's Bluetooth system can allow you to get text messages that are sent to your mobile phone from the MMI system.

1. Establish Bluetooth connection.
2. Configure your mobile phone. Select option 2a or 2b depending on you device.
 - 2a. With an Android phone, you will be prompted to enable MAP as you establish the connection.
 - 2b. For iPhone, enable Show notifications from Bluetooth properties of your connection.
 - ▶ Upon activating Show notifications, some phones may require Bluetooth to be temporarily turned off on the device to force the MMI system to identify the new setting. Once Bluetooth is turned back on, the MMI will recognize the new setting and Read messages will be active.

The new message notification will be displayed at the bottom of the MMI display. To access and read your messages:

1. Select the TEL function.
2. Select Messages and press the control knob to view messages.

Or you can press the TALK button and say, "Read message". The MMI system will read any new text message to you.



Wireless Audio Streaming


When your Bluetooth device is paired to your Audi vehicle, it allows you to stream music wirelessly from your device through the vehicle's stereo system. (Refer to Bluetooth pairing instructions to pair a device.) To ensure that Bluetooth Audio is enabled on the MMI system:

1. Select the TEL function » Settings » Bluetooth » Bluetooth Audio » then choose the "On" option.
2. Select the MEDIA function » Source » Bluetooth.
3. Select from Artists, Albums, Songs and more to make your selection.

To return to the previous screen, press the BACK button or Browse control button to make another selection.

Your Bluetooth Wireless Audio Is Also Capable of Streaming Audio from Other Apps Too:

- ▶ To begin playing from another app or restarting audio stored on your device, start the app from the device.
- ▶ If your device is currently connected with Bluetooth and plugged into the USB port, The Bluetooth audio connection will be turned off.
- ▶ To re-establish the Bluetooth connection, remove the connection to the USB port and select the Bluetooth source and follow the prompts to turn Bluetooth Audio back on.



Voice Recognition

Call by Name

1. Press the TALK button on the steering wheel. A beep will sound.
 2. Say "Call" <Name from directory> (e.g., "Call John Smith").
 3. To confirm the request, say "Yes". The number will be dialed.
 4. To end a call, press the left thumbwheel on the steering wheel.
- ▶ If multiple numbers are stored for a given contact, the system will ask which number you wish to dial. When calling by name using Voice Recognition, you must say the name as it is stored in your phone book.



Refer to your Owner's Manual for additional commands.

Setting a Destination

1. Press the TALK button on the steering wheel. A beep will sound.
2. Say "Enter address". See Owner's Manual for complete list of commands.
3. After the beep, speak the address; for example, "Two-Zero-Two-Four Main Street, Los Angeles". (Speak single digits.)
 - ▶ If destination is in another state, say "Change state" when prompted to enter address.
4. The system will repeat the address for confirmation and ask if you would like to start route guidance. After the beep say "Yes" and guidance will begin.

There are three options to cancel Voice Recognition:

- ▶ Simply say "Cancel" at the voice prompt.
- ▶ Press any button on the MMI controls.
- ▶ Or press and hold the TALK button until you hear "Cancel".



Indicator Lights

MY18-A7-01

For additional information on indicator lights, refer to your vehicle's Owner's Manual.

 BRAKE	Brake system		Central indicator light		Tank system		Brake booster, Central indicator light
 PARK	Electromechanical parking brake		Electronic Stabilization Control (ESC)		Washer fluid level		Electromechanical power steering, dynamic steering
	Cooling system		Electronic Stabilization Control (ESC)		Windshield wipers		Rear spoiler
	Engine oil pressure		Electronic Stabilization Control (ESC)		Remote control key		Air suspension
	Engine oil level (MIN)		Anti-lock braking system (ABS)		Remote control key		Sport differential
	Alternator		Safety systems		Battery in remote control key		Turn signals
	Engine stops while driving		Brake pads		Bulb failure indicator		Cruise control system
	Front safety belt		Electromechanical parking brake		Rear fog lights		Adaptive cruise control
	Electromechanical steering		Tire pressure		Headlight range control system		Adaptive cruise control
	Steering lock		Tire pressure		Adaptive light		Adaptive cruise control
	Engine start system		Engine control (gasoline engine)		Light/rain sensor		Active lane assist
	Speed warning system		Malfunction indicator lamp (MIL)		Active lane assist		Start/Stop system
	Adaptive cruise control		Engine speed limitation		Suspension control		Start/Stop system
	Air suspension		Engine oil level (MIN)		Transmission		High beam assistant
	Rear spoiler		Engine oil sensor		Transmission		High beams
	Night vision assist		Engine warm-up request		Steering lock		
	Night vision assist		Battery charge		Engine start system		



To learn more about how to operate the features within your Audi.

TEXT 2018A7 to 38981

Do not text and drive.
Message and data rates may apply.

To learn more about your features, call your Audi technologist.
1-855-750-TECH (8324).



You can have Audi feature information on demand with the myAudi IQ app, which delivers video demos for your Audi. Download the iOS app* now and put Audi knowledge in your pocket.

*Requires iOS 7.0 or later and available on iPad® only.

Audi Customer Support (800) 822-2834

The information within this guide must be used in conjunction with the information in the Audi Owner's Manual. Refer to your vehicle's Owner's Manual for all information and warnings. By using this guide, you acknowledge that you are aware of and have read the warnings and information provided in the Owner's Manual on the topics in this guide and will use this information to augment that material. Always pay careful attention to the road, and do not drive while distracted.

©2017 Audi of America, Inc. All rights reserved.